



Scan to go to website

## Dante Speaker Application Installation Instructions

This guide helps you install & update the **Dante Speaker Application** applicable for all of Kramer Dante Speakers.

### Step 1: Introduction

The Dante Speaker Application is required for configuration and operating Kramer's Dante-enabled speakers. The following table lists the supported products:

✔ AW-6D	✔ WM-6D	✔ CL-6D
✔ AW-8D	✔ WM-8D	✔ CL-8D


### Step 2: Installing Dante Speaker Application

#### 2.1 Downloading the Installer


1. Download the setup file from the official link:  
<https://kramer-speaker-manager.s3.us-east-1.amazonaws.com/updates/Kramer-Speaker-Manager-Setup.exe>

#### 2.2 Performing the Installation


1. Locate the downloaded .exe file in your **Downloads** folder and double-click to start the installation.




2. When installation is complete, the following prompt asks if you want to launch the app.
3. Click **Yes, launch now** to open the app immediately, or **No, thanks** to launch at a later time.



4. The app automatically checks for updates. When a new version is available, you will see a message like the one shown below.
5. Click **Yes, Download** to begin updating.




6. While the update is downloading, you'll see a progress indicator as shown below.



7. Once the download is complete, you'll be prompted to restart the app to apply the update.

8. Click **Restart Now** to finish updating.



To Manually check for updates at any given time:

1. Click the **info (i) icon** at the top corner of the app.
2. You will see the current version and the option to trigger an update if a newer version is available.

